

Refrigerator Action Guide – When To Call VFC (°F)

Action steps are different because vaccines respond differently to WARM and COLD temperatures and the amount of time at these temperatures. Post this guide on the refrigerator to help you take the correct actions.

MIN TOO COLD

28° & colder 29° 30° 31° 32° 33° 34° 34.9°

1. Press MEMORY CLEAR/RESET button(s) after recording temperatures.
2. Post "Do Not Use Vaccine" sign.
3. Alert your supervisor.

Call VFC Call Center!
1-877-243-8832


Press MEMORY CLEAR/RESET button(s).

Document all actions taken.

CURRENT, MIN, and MAX are all OK.

35.0° 36° 37° 38° 39° 40° 41° 42 43° 44° 45° 46.0°

1. Press MEMORY CLEAR/RESET button(s). Done. No need to call VFC.



Make sure that MIN and MAX show on the display and not alarm settings (LO and HI).

MAX TOO WARM

46.1° 47° 48° 49° 50° 51° 52° 53° 54° & warmer

1. Press MEMORY CLEAR/RESET button(s) after recording temperatures.
2. Post "Do Not Use Vaccine" sign.
3. Alert your supervisor.

A.M. recording

P.M. recording

Call VFC Call Center!
1-877-243-8832

Wait 1 hour & check temperatures again.

CURRENT TOO WARM

CURRENT OK

Call VFC Call Center!
1-877-243-8832

No need to call VFC (unless this happens daily).

Press MEMORY CLEAR/RESET button(s).

Document all actions taken.

If you are not sure if there is a problem, call:

California Vaccines for Children Program **VFC Call Center: 1-877-243-8832**